HEAT TRANSFER

[CH21204]

April 06, 2023


Film Boiling

$$\dot{q}_{\text{film}} = C_{\text{film}} \left[\frac{gk_{\nu}^{3} \, \rho_{\nu} \, (\rho_{l} - \rho_{\nu}) [h_{fg} + 0.4C_{p\nu} \, (T_{s} - T_{\text{sat}})}{\mu_{\nu} \, D(T_{s} - T_{\text{sat}})} \right]^{1/4} (T_{s} - T_{\text{sat}})$$


$$C_{\text{film}} = \begin{cases} 0.62 \text{ for horizontal cylinders} \\ 0.67 \text{ for spheres} \end{cases}$$

- vapor properties are to be evaluated at the film/average temperature
- liquid properties and h_{fg} are to be evaluated at the saturation temperature at the specified pressure


FLOW BOILING



CONDENSATION HEAT TRANSFER



Dropwise condensation is the preferred mode of condensation in heat transfer applications!



$$\operatorname{Re} = \frac{D_h \, \rho_l \, \mathcal{V}_l}{\mu_l} = \frac{4 \, A_c \, \rho_l \, \mathcal{V}_l}{p \mu_l} = \frac{4 \, \rho_l \, \mathcal{V}_l \, \delta}{\mu_l} = \frac{4 \, \dot{m}}{p \mu_l}$$

 $D_h = 4A_c/p = 4\delta$ = hydraulic diameter of the condensate flow, m

p = wetted perimeter of the condensate, m


 $A_c = p\delta$ = wetted perimeter × film thickness, m², cross-sectional area of the condensate flow at the lowest part of the flow


 ρ_l = density of the liquid, kg/m³

 μ_l = viscosity of the liquid, kg/m · s

 $\mathcal{V}=$ average velocity of the condensate at the lowest part of the flow, m/s

 $\dot{m} = \rho_l \mathcal{V}_l A_c = \text{mass flow rate of the condensate at the lowest part, kg/s}$





$$h_{\text{vert}} = 0.943 \left[\frac{g \rho_l (\rho_l - \rho_{\nu}) h_{fg}^* k_l^3}{\mu_l (T_{\text{sat}} - T_{\nu}) L} \right]^{1/4}$$
 (W/m² · °C), 0 < Re < 30

 $g = gravitational acceleration, m/s^2$

 ρ_l , ρ_{ν} = densities of the liquid and vapor, respectively, kg/m³

 μ_l = viscosity of the liquid, kg/m · s

 $h_{fg}^* = h_{fg} + 0.68C_{pl}(T_{sat} - T_s) = \text{modified latent heat of vaporization, J/kg}$

 k_l = thermal conductivity of the liquid, W/m · °C

L = height of the vertical plate, m

 T_s = surface temperature of the plate, °C

 $T_{\rm sat}$ = saturation temperature of the condensing fluid, °C

DROPWISE CONDENSATION

$$h_{\text{dropwise}} = \begin{cases} 51,104 + 2044T_{\text{sat}}, & 22^{\circ}\text{C} < T_{\text{sat}} < 100^{\circ}\text{C} \\ 255,310 & T_{\text{sat}} > 100^{\circ}\text{C} \end{cases}$$

